

GENUINE RIGGING-PARTS AND ACCESSORIES



SUZUKI MOTOR CORPORATION reserves the right to add any improvement to change the design or to discontinue any item at any time without notice. Some items might not be compatible with local standards or statutory requirements. Please check with your local AUTHORIZED SUZUKI DEALER for details at the time of ordering. Actual colors might differ from those appearing in this catalogue.

©2009 SUZUKI MOTOR CORPORATION. All rights reserved.
Printed in Japan. © October 2009. Part number: 99000-79N12-047

SUZUKI MOTOR CORPORATION
300 TAKATSUKA, MINAMI, HAMAMATSU, JAPAN

Your AUTHORIZED SUZUKI DEALER

BEFORE YOU SAIL OUT, CHECK YOUR MOTOR AND FUEL FOLLOWING THE OWNER'S MANUAL, AND WEAR PROPER ATTIRE.



Way of Life!

GENUINE RIGGING-PARTS AND ACCESSORIES

Dear Customer,

Quality. Dependability. Innovation. Everything that you expect from your outboard motors is delivered with style by SUZUKI. Demand no less from the products that you choose to enhance your total boating pleasure. Demand GENUINE SUZUKI ACCESSORIES. This catalogue represents our commitment to provide you with the finest products available. From our classic line of matching instruments and gauges to our custom-engineered propellers and rigging items, you can depend on GENUINE SUZUKI ACCESSORIES for optimum performance. Take a few minutes to browse through this catalogue, and then be sure to visit your AUTHORIZED SUZUKI DEALER for the complete ordering information. Thank you.

SUZUKI MOTOR CORPORATION

TABLE OF CONTENTS

INSTRUMENT	ELECTRONIC INSTRUMENT	04
	GAUGE CONNECTION CHART	06
	ANALOG INSTRUMENT	08
CONTROL SYSTEM	SPC ELECTRONIC THROTTLE AND SHIFT SYSTEM	12
	MECHANICAL REMOTE CONTROL SYSTEM	16
STEERING		20
ELECTRICAL PARTS		22
ANODE		23
FUEL SYSTEM		24
PROPELLER		26
CARE ITEM		28
MAINTENANCE ITEM		28
APPLICATION CHART		30

NOTE

Items and their part numbers showing in this catalogue are basically applicable to 2010 model year models of engines. Please consult your local dealers regarding other year models and their rigging-parts and accessories.

REFERENCE

Part Number	15-digit alpha-numerical number shows Part Number to be used for ordering.
Gauge Size	Shows the size (2" or 4") of the gauge.
Background	Shows a main color of display panel on the front of a gauge.
Applicable Model	Shows typical or recommended models of ENGINES that RIGGING-PARTS and ACCESSORIES can be installed to.
Maximum Speed	Shows maximum speed that SPEEDOMETER displays.
kph	Kilo-meter Per Hour
mph	Miles Per Hour

2010 MODEL LINE UP

DF300T	DF175T	DF90AT	DF25	DF9.9A
DF300Z	DF175Z	DF80AT	DF25R	DF9.9AR
		DF70AT		
DF250T	DF150T	DF60AT	DF15	DF8A
DF250Z	DF150Z	DF60ATH	DF15R	DF8AR
DF225T	DF140T	DF50T	DF9.9T	DF6
DF225Z	DF140Z	DF50TH	DF9.9TH	DF5
				DF4
DF200T	DF115T	DF40T		
DF200Z	DF115Z	DF40QH		DF2.5
	DF100T			

EXAMPLES OF APPLICABLE MODELS

	INVOLVED MODELS	NOT INVOLVED MODELS
DF8A-9.9AR	DF8A, DF8AR, DF9.9A and DF9.9AR	DF9.9T and DF9.9R
DF8A/9.9AR	DF8A and DF9.9AR	
DF9.9T-15R	DF9.9T, DF9.9TH, DF15 and DF15R	
DF9.9T/15/15R	DF9.9T, DF15 and DF15R	DF9.9TH
DF25/25R	DF25 and DF25R	
DF70AT-90AT	DF70AT, DF80AT and DF90AT	
DF70AT/90AT	DF70AT and DF90AT	
DF150T/Z-175T/Z	DF150T, DF150Z, DF175T and DF175Z	
DF150T/175T	DF150T and DF175T	DF150Z and DF175Z
DF250T/Z-300T/Z	DF250T, DF250Z, DF300T and DF300Z	
DF300T/Z	DF300T and DF300Z	

ELECTRONIC INSTRUMENT

TACHOMETER



34200-98J13-000 001
 Gauge Size 4"
 Background White
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A

Readout	Unit	Required item for displaying
Engine RPM	rpm	
Cylinder temperature	°C or °F	
Engine-operating hour	hours	
Atmospheric pressure	kPa or lhg	
Fuel-flow amount	litre/hour or gallons/hour	
Cooling-water pressure	kPa or psi	Available on DF70A-90A/300 with WATER-PRESSURE-SENSOR KIT (34970-98J01-000)
Intake-manifold pressure	kPa or psi	
Trim angle	%	
Battery voltage	Vdc	

WARNING ALARMS
 Engine Over Rev, Engine Overheat, Low Oil Pressure, Low Battery Voltage, Oil Change Reminder, and Check Engine Warning.

SPEEDOMETER



34100-98J11-000 002
 Gauge Size 4"
 Background White
 Maximum Speed 130km/h, 80mph
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A



34100-98J41-000 003
 Gauge Size 4"
 Background White
 Maximum Speed 110km/h, 60knots
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A

Readout	Unit	Required item for displaying
Speed over water	kph, mph or knots	*Transducer with speed input for DF40-250
Speed over ground	kph, mph or knots	*NMEA 2000 GPS receiver/antenna connection
Remaining fuel	%	*Fuel-sender (Resistor type)
Fuel-flow rate	litre or US-gallon	
Fuel consumption	kms/litre or miles/US-gallon	*NMEA 2000 GPS receiver/antenna connection
Fuel used	litre or US-gallon	
Trip log	kms or miles	*NMEA 2000 GPS receiver/antenna connection
Water depth	meter / feet	*NMEA 2000 transducer with water-depth input
Seawater temperature	°C or °F	*NMEA 2000 transducer with seawater temperature input

QUICK REFERENCE CHART for SPEEDOMETERS

Part number	Background	km/h	mph	knots	Applicable models
34100-98J11-000 002	White	130	80	-	DF40T-300T/Z
34100-98J41-000 003	White	110	-	60	DF40T-300T/Z

Note: Not applicable for DF60A.

SPEEDOMETER-SUB KIT



34120-98J01-000 004
 Applicable Model DF70A-90A/300T/Z

Contents:	Part Number	Qty/Kit
SPEEDOMETER SENDER	34190-95500-000 034	1
SPEEDOMETER-HOSE UNION	55127-87D00-000	1
HOSE		1

Contents:	Part Number	Qty/Kit
CLAMP (L: 100 mm)	09407-10404-000	2

Use SPEEDOMETER SENDER (34190-95500-000) in case that the integrated sender cannot detect a proper boat-speed.

FUEL GAUGE



34300-98J10-000 005
 Gauge Size 2"
 Background White
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A

VOLTMETER



34600-98J10-000 006
 Gauge Size 2"
 Background White
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A

TRIM GAUGE



34800-98J10-000 007
 Gauge Size 2"
 Background White
 Applicable Model DF40T-300T/Z
 Not Applicable Model DF60A

WATER-PRESSURE GAUGE



34650-98J10-000 008
 Gauge Size 2"
 Background White
 Applicable Model DF70A-90A/300T/Z
 Not Applicable Model DF60A

WATER-PRESSURE-SENSOR KIT



34970-98J01-000 009
 In case of use as WATER-PRESSURE SENSOR
 Applicable Model DF70A-90A/300T/Z
 In case of use as SPEED SENSOR
 Applicable Model DF70A-90A

This kit can be installed as a water pressure sensor or as a speed sensor. The detail is described in the installation manual, which is contained in the package. Previous version of kit (34970-98J00-000) functions only as a water-pressure sensor for DF300T/Z.

Contents:	Quantity		
	in KIT	used for water-pressure sensor	used for speed sensor
1 Sensor	1	1	1
2 Connector	1	1	1
3 Bolt	1	1	1
4 Clip	4	4	1
5 3-way	1	1	-
6 Water-pressure hose (500mm)	1	1	-
7 Cap	1	-	1

WATER-PRESSURE-SENSOR KIT (34970-98J01-000) is required for installation to DF70A-90A/300T/Z.

CONNECTION between ENGINE and INSTRUMENT

ACTIVE-HUB UNIT



34921-98J00-000 010
 Applicable Model DF40T-300T/Z

PASSIVE-HUB UNIT



34921-98J10-000 011
 Applicable Model DF40T-300T/Z

INTERFACE UNIT



34922-98J02-000 012
 Applicable Model DF40T-300T/Z

Previous version of INTERFACE UNIT (34922-98J01-000) is not applicable to DF70A-90A.

INTERFACE-UNIT ADAPTER



36661-93J00-000 013
 Applicable Model DF40T-250T/Z

INTERFACE-UNIT HARNESS



36661-98J00-000 014
 Applicable Model DF40T-300T/Z

INTERFACE-UNIT-ADAPTER LEAD



36646-87L00-000 015
 Applicable Model DF70A-90A

HUB HARNESS



36662-98J00-000 016
 1.0 meter
 Applicable Model DF40T-300T/Z

36662-98J10-000

6.5 meters
 Applicable Model DF40T-300T/Z

4-INCH-GAUGE CONNECT KIT

34011-98J02-000

Applicable Model DF40T-300T/Z

Contents:	Part Number	Qty/Kit
ACTIVE-HUB UNIT	34921-98J00-000 010	1
INTERFACE UNIT	34922-98J02-000 012	1
INTERFACE-UNIT HARNESS	36661-98J00-000 014	1
JUMPER WIRE	36665-98J00-000 021	1

4-INCH-GAUGE HARNESS with a 6-PIN CONNECTOR CAP (36666-98J10-000)
 36664-98J00-000 017 1
 6-PIN CONNECTOR CAP 36666-98J10-000 020 2

Previous version of kit (34011-98J01-000) is not applicable to DF60A-90A.

4-INCH-GAUGE HARNESS



36664-98J00-000 017
 with a 6-PIN CONNECTOR CAP (36666-98J10-000)
 Applicable Model DF40T-300T/Z

2-INCH-GAUGE HARNESS



36664-98J10-000 018
 Applicable Model DF40T-300T/Z

ACTIVE-HUB POWER HARNESS

36663-98J00-000

2.5 meters
 Applicable Model DF40T-300T/Z



36663-98J10-000 019
 6.0 meters
 Applicable Model DF40T-300T/Z

2-PIN CONNECTOR CAP

36667-98J00-000

Applicable Model DF40T-300T/Z

6-PIN CONNECTOR CAP



36666-98J10-000 020
 Applicable Model DF40T-300T/Z

8-PIN CONNECTOR CAP

36666-98J00-000

Applicable Model DF40T-300T/Z

JUMPER WIRE



36665-98J00-000 021
 Applicable Model DF40T-300T/Z

RESISTOR HARNESS



36668-98J00-000 022
 Applicable Model DF300T/Z

GAUGE-CONNECTION CHART

ENGINE(S)	1			2			3		
STATION(S)	2			1			1		
	total	1st	2nd	total	1st	2nd	total	1st	2nd

Note: • Numbers between parentheses show the maximum quantities required.
 • "KIT" in cells means the content of 4-INCH-GAUGE CONNECT KIT (34011-98J02-000).
 • All signals go through the tachometer and are distributed to other gauges.
 It is essential to use the tachometer to bring the other gauges active.

Category	Part Name & Description	Quantity Of Parts To Be Used Per Boat	Remarks		
for DF300	4-INCH GAUGE (White)	SPEEDOMETER Maximum speed: 130 kph / 80 mph Maximum speed: 110 kph / 60 knots	34100-98J11-000 ⁰⁰² 34100-98J41-000 ⁰⁰³ 34120-98J01-000 ⁰⁰⁴ 34200-98J13-000 ⁰⁰¹	(1) (2) (1) (1) (1) (2) (1) (1) (1) (2) (1) (1)	
		SPEEDOMETER-SUB KIT	34120-98J01-000 ⁰⁰⁴	(1) (1) - - (1) (1) - - (1) (1) - -	This additional sender provides more accurate boat speed than the standard sender does.
		TACHOMETER	34200-98J13-000 ⁰⁰¹	1 2 1 1 2 4 2 2 3 6 3 3	
	2-INCH GAUGE (White)	FUEL GAUGE	34300-98J10-000 ⁰⁰⁵	(1) (2) (1) (1) (1) (2) (1) (1) (1) (2) (1) (1)	FUEL GAUGE(S) displays the residual amount of fuel in #1 FUEL TANK only.
		VOLT METER	34600-98J10-000 ⁰⁰⁶	(1) (2) (1) (1) (1) (2) (4) (2) (2) (3) (6) (3) (3)	
		WATER PRESSURE GAUGE	34650-98J10-000 ⁰⁰⁸	(1) (2) (1) (1) (2) (4) (2) (2) (3) (6) (3) (3)	WATER-PRESSURE-SENSOR KIT must be used together with WATER PRESSURE GAUGE(S). Quantity of KIT is equal to one of the installed engines.
		WATER-PRESSURE-SENSOR KIT	34970-98J01-000 ⁰⁰⁹	(1) (1) (1) - (2) (2) (2) - (3) (3) (3) -	
		TRIM GAUGE	34800-98J10-000 ⁰⁰⁷	(1) (2) (1) (1) (2) (4) (2) (2) (3) (6) (3) (3)	
	GAUGE-CONNECTION HARDWARE	4-INCH-GAUGE CONNECT KIT *Contents are shown in the chart below.	34011-98J02-000	1 1 1 - - - - - - - - - -	"KIT" in orange cells means "the included item(s) in 4-INCH-GAUGE CONNECT KIT".
		ACTIVE-HUB UNIT	34921-98J00-000 ⁰¹⁰	KIT KIT KIT - 1 1 1 - 1 1 1 -	
PASSIVE-HUB UNIT		34921-98J10-000 ⁰¹¹	- - - - - 1 - 1 - 2 1 1		
RESISTOR HARNESS		36668-98J00-000 ⁰²²	- 1 - 1 - - - - - - - -	RESISTOR HARNESS must be used in stead of PASSIVE HUB UNIT (34921-98J10-000).	
INTERFACE UNIT		34922-98J02-000 ⁰¹²	KIT KIT KIT - 1 1 1 - 1 1 1 -		
INTERFACE-UNIT HARNESS		36661-98J00-000 ⁰¹⁴	KIT KIT KIT - 1 1 1 - 1 1 1 -		
HUB HARNESS		36662-98J00-000 ⁰¹⁶	- - - - - - - - - 1 1 -		
HUB HARNESS		36662-98J10-000	- 1 1 - - - 1 1 - - 1 1 -		
ACTIVE-HUB POWER HARNESS		36663-98J00-000	1 1 1 - 1 1 1 - 1 1 1 -	Select one according to the distance from battery.	
ACTIVE-HUB POWER HARNESS		36663-98J10-000 ⁰¹⁹	1 1 1 - 1 1 1 - 1 1 1 -		
4-INCH-GAUGE HARNESS with a 6-PIN CONNECTOR CAP (36666-98J10-000)		36664-98J00-000 ⁰¹⁷	KIT KIT+1 KIT 1 2 4 2 2 3 6 3 3	A 6-PIN CONNECTOR CAP (36666-98J10-000) is included.	
2-INCH-GAUGE HARNESS		36664-98J10-000 ⁰¹⁸	▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶	▶▶ Quantity of 2-INCH GAUGE HARNESS is equal to the total quantity of 2-INCH GAUGE.	
JUMPER WIRE		36665-98J00-000 ⁰²¹	KIT KIT KIT - 1 1 1 - 1 1 1 -		
8-PIN CONNECTOR CAP		36666-98J00-000	(1) (2) (1) (1) (2) (4) (2) (2) (3) (6) (3) (3)	8-PIN CONNECTOR CAP installed in case that no speedometer is used.	
6-PIN CONNECTOR CAP		36666-98J10-000 ⁰²⁰	KIT KIT+1 KIT - 1 1 - 1 0 1 1 -	6-PIN CONNECTOR CAP is included in 4-INCH GAUGE HARNESS (36664-98J00-000).	
2-PIN CONNECTOR CAP	36667-98J00-000	- 1 1 - - - 1 1 - 0 2 2 -			
BATTERY ISOLATOR LEAD SET	33830-98J01-000	(1) (1) (1) - (1) (1) (1) - (1) (1) (1) -	BATTERY ISOLATOR LEAD SET is required in case that an auxiliary battery for supplying power to accessories is used.		
REMOTE-CONTROLSYSTEM	REMOTE-CONTROL KIT *Contents are shown in the page 12-13.	Binnacle-mount for Single-engine + Single (First) -station	67000-98J03-000	1 1 1 - - - - - - - -	
		Flush-mount for Single-engine + Single (First) -station	67000-98J61-000	- 1 - 1 - - - - - - - -	
		Binnacle-mount for Single-engine + Second-station	67000-98J10-000	- - - - - 1 1 1 - - - - -	
		Binnacle-mount for Dual-engine + Single (First) -station	67000-98J23-000	- - - - - 1 1 1 - - - - -	
		Binnacle-mount for Dual-engine + Second-station	67000-98J32-000	- - - - - 1 - 1 - - - - -	
		Binnacle-mount for Triple-engine + Single (First) -station	67000-98J42-000	- - - - - - - - - 1 1 1 -	
	Binnacle-mount for Triple-engine + Second-station	67000-98J52-000	- - - - - - - - - 1 - 1 -		
	MAIN WIRING HARNESS	36620-98J00-000 ⁰⁵⁹	1 2 1 1 1 2 1 1 1 2 1 1	Select one according to the boat length.	
	MAIN WIRING HARNESS	36620-98J10-000	▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶	▶▶ Quantity depends on the length required.	
	MAIN-WIRING-HARNESS EXTENSION	36620-98J20-000	▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶ ▶▶	▶▶ Quantity depends on the length required.	

Category	Part Name & Description	Quantity Of Parts To Be Used Per Boat	Remarks
CONTENTS OF 4-INCH-GAUGE CONNECT KIT (34011-98J02-000)	ACTIVE-HUB UNIT	34921-98J00-000 ⁰¹⁰	1 1 1 - - - - - - - -
	INTERFACE UNIT	34922-98J02-000 ⁰¹²	1 1 1 - - - - - - - -
	INTERFACE-UNIT HARNESS	36661-98J00-000 ⁰¹⁴	1 1 1 - - - - - - - -
	JUMPER WIRE	36665-98J00-000 ⁰²¹	1 1 1 - - - - - - - -
	4-INCH-GAUGE HARNESS with a 6-PIN CONNECTOR CAP (36666-98J10-000)	36664-98J00-000 ⁰¹⁷	1 1 1 - - - - - - - -
	6-PIN CONNECTOR CAP	36666-98J10-000 ⁰²⁰	2 2 2 - - - - - - - -

※ Previous version of kit (34011-98J01-000) is not applicable to DF60A-90A.

ENGINE(S)	1	2	3
STATION	1	1	1

Note: • Numbers between parentheses show the maximum quantities required.
 • "KIT" in cells means the content of 4-INCH-GAUGE CONNECT KIT (34011-98J02-000).
 • All signals go through the tachometer and are distributed to other gauges.
 It is essential to use the tachometer to bring the other gauges active.

Category	Part Name & Description	Quantity Of Parts To Be Used Per Boat	Remarks		
for DF40-250 Without DF60A	4-INCH GAUGE (White)	SPEEDOMETER Maximum speed: 130 kph / 80 mph Maximum speed: 110 kph / 60 knots	34100-98J11-000 ⁰⁰² 34100-98J41-000 ⁰⁰³ 34190-95500-000 ⁰³⁴ 34200-98J13-000 ⁰⁰¹	(1) (1) (1)	Requires NMEA 2000 transducer with speed input or a NMEA 2000 GPS receiver/antenna.
		SPEEDOMETER SENDER	34190-95500-000 ⁰³⁴	(1) (1) (1)	Only for DF70AT/80AT/90AT. For other models, DF40/50/100-250, either a NMEA 2000 certified speed sender or an analog-type of sender available in the market can be used.
		TACHOMETER	34200-98J13-000 ⁰⁰¹	1 2 3	
	2-INCH GAUGE (White)	FUEL GAUGE	34300-98J10-000 ⁰⁰⁵	(1) (1) (1)	Requires input from a widely-purchasable potentiometer-type of fuel level sensor.
		VOLT METER	34600-98J10-000 ⁰⁰⁶	(1) (1) (1)	
		WATER PRESSURE GAUGE	34650-98J10-000 ⁰⁰⁸	(1) (1) (1)	Only for DF70AT/80AT/90AT.
		TRIM GAUGE	34800-98J10-000 ⁰⁰⁷	(1) (2) (3)	
	GAUGE-CONNECTION HARDWARE	4-INCH-GAUGE CONNECT KIT *Contents are shown in the chart above.	34011-98J02-000	1 - -	
		ACTIVE-HUB UNIT	34921-98J00-000 ⁰¹⁰	KIT 1 1	
		INTERFACE UNIT	34922-98J02-000 ⁰¹²	KIT 1 1	
INTERFACE-UNIT HARNESS		36661-98J00-000 ⁰¹⁴	KIT 1 1		
INTERFACE-UNIT ADAPTER		36661-93J00-000 ⁰¹³	1 1 1		
INTERFACE-UNIT-ADAPTER LEAD		36646-87L00-000 ⁰¹⁵	(1) (1) (1)	Required for DF70AT/80AT/90AT only.	
ACTIVE HUB POWER HARNESS		36663-98J00-000	1 1 1	Select one according to the distance from battery.	
ACTIVE HUB POWER HARNESS		36663-98J10-000 ⁰¹⁹	1 1 1		
4-INCH-GAUGE HARNESS with a 6-PIN CONNECTOR CAP (36666-98J10-000)		36664-98J00-000 ⁰¹⁷	KIT 2 3	A 6-PIN CONNECTOR CAP (36666-98J10-000) is included.	
2-INCH-GAUGE HARNESS		36664-98J10-000 ⁰¹⁸	▶▶ ▶▶ ▶▶	▶▶ Quantity of 2-INCH GAUGE HARNESS is equal to the total quantity of 2-INCH GAUGE.	
JUMPER WIRE	36665-98J00-000 ⁰²¹	KIT 1 1			
8-PIN CONNECTOR CAP	36666-98J00-000	(1) (1) (1)	Installed in case that no speedometer is used.		
6-PIN CONNECTOR CAP	36666-98J10-000 ⁰²⁰	KIT 1 0			

ANALOG INSTRUMENT



TACHOMETER



34200-93J20-000 023

Gauge Size	4"
Background	Black
Applicable Model	DF8AR/9.9T/9.9R/9.9AR/15R/25R

Full-scale 7000-RPM TACHOMETER can be used on electric-start models by using 4, 6 or 12 pole switch on rear of meter.



34200-93J31-000 024

Gauge Size	4"
Background	White
Applicable Model	DF8AR/9.9T/9.9R/9.9AR/15R/25R

Full-scale 7000-RPM TACHOMETER can be used on electric-start models by using 4, 6 or 12 pole switch on rear of meter.



34200-93J00-000 025

Gauge Size	4"
Background	Black
Applicable Model	DF40T-250T/Z

Caution systems alert with a monitor lamp lighting on when an abnormal engine condition occurs. Refer to SERVICE MANUAL for the detail.



34200-93J11-000 026

Gauge Size	4"
Background	White
Applicable Model	DF40T-250T/Z

Caution systems alert with a monitor lamp lighting on when an abnormal engine condition occurs. Refer to SERVICE MANUAL for the detail.

SPEEDOMETER



34100-93J00-000 027

Gauge Size	4"
Background	Black
Maximum Speed	130km/h, 80mph
Applicable Model	DF40T-250T/Z

Bourdon-tube type speedometer with readings in km/h and mph. Includes vinyl tube, hardware and installation manual.



34100-93J11-000 028

Gauge Size	4"
Background	White
Maximum Speed	130km/h, 80mph
Applicable Model	DF40T-250T/Z

Bourdon-tube type speedometer with readings in km/h and mph. Includes vinyl tube, hardware and installation manual.



34100-93J40-000 031

Gauge Size	4"
Background	Black
Maximum Speed	80km/h, 45knots
Applicable Model	DF25R-250T/Z

Bourdon-tube type speedometer with readings in km/h and knots. Includes vinyl tube, hardware and installation manual.



34100-93J51-000 032

Gauge Size	4"
Background	White
Maximum Speed	80km/h, 45knots
Applicable Model	DF25R-250T/Z

Bourdon-tube type speedometer with readings in km/h and knots. Includes vinyl tube, hardware and installation manual.



34100-93J20-000 029

Gauge Size	4"
Background	Black
Maximum Speed	80km/h, 50mph
Applicable Model	DF25R-115T/Z/140T-250T/Z
Not Applicable Model	DF140Z

Bourdon-tube type speedometer with readings in km/h and mph. Includes vinyl tube, hardware and installation manual.



34100-93J31-000 030

Gauge Size	4"
Background	White
Maximum Speed	80km/h, 50mph
Applicable Model	DF25R-250T/Z

Bourdon-tube type speedometer with readings in km/h and mph. Includes vinyl tube, hardware and installation manual.



34100-93J60-000 033

Gauge Size	4"
Background	White
Maximum Speed	120km/h, 65knots
Applicable Model	DF60AT-250T/Z

Bourdon-tube type speedometer with readings in km/h and knots. Includes vinyl tube, hardware and installation manual.

SPEEDOMETER SENDER



34190-95500-000 034

Applicable Model	DF25R-300T/Z
------------------	--------------



34190-87D00-000 035

Applicable Model	DF25R-250T/Z
Not Applicable Model	DF60A

Each of DF60-300 models has an integrated SPEEDOMETER SENDER as standard. In case that the integrated sender cannot detect a proper boat-speed, use SPEEDOMETER SENDER.

QUICK REFERENCE CHART for SPEEDOMETERS

part number	Background	km/h	mph	knots	Applicable models
34100-93J00-000 027	Black	130	80	-	DF40T-250T/Z
34100-93J11-000 028	White	130	80	-	DF40T-250T/Z
34100-93J20-000 029	Black	80	50	-	DF25R/40T-250T/Z
34100-93J31-000 030	White	80	50	-	DF25R/40T-250T/Z
34100-93J40-000 031	Black	80	-	45	DF25R/40T-250T/Z
34100-93J51-000 032	White	80	-	45	DF25R/40T-250T/Z
34100-93J60-000 033	White	120	-	65	DF70AT-250T/Z

Caution lamp	Caution type
CHECK ENGINE	Low battery-voltage or Other cautions on S.D.S
TEMP	Overheat (Over-revolution)
OIL	Low oil-pressure (Over-revolution) Oil change reminder
REV LIMIT	Over-revolution

ANALOG INSTRUMENT



FUEL GAUGE



34300-93J00-000 036

Gauge Size	2"
Background	Black
Applicable Model	DF25R/40T-250T/Z

FUEL GAUGE alone works with the US Standard 250Q sending unit. Use the 150Q adaptor to connect the gauge to a European standard sending unit.

HOUR METER



34500-93J00-000 038

Gauge Size	2"
Background	Black
Applicable Model	DF25R-250T/Z

12-volt-electric-motor-driven meter indicates hours that your outboard motor has been operated in order for you to know when each periodic service is required.

VOLTMETER



34600-93J00-000 040

Gauge Size	2"
Background	Black
Applicable Model	DF25R-250T/Z

To help your SUZUKI OUTBOARD MOTOR run at its best, monitor the charging system functioning with a VOLTMETER.



34300-93J11-000 037

Gauge Size	2"
Background	White
Applicable Model	DF25R/40T-250T/Z

FUEL GAUGE alone works with the US Standard 250Q sending unit. Use the 150Q adaptor to connect the gauge to a European standard sending unit.



34500-93J11-000 039

Gauge Size	2"
Background	White
Applicable Model	DF25R-250T/Z

12-volt-electric-motor-driven meter indicates hours that your outboard motor has been operated in order for you to know when each periodic service is required.



34600-93J11-000 041

Gauge Size	2"
Background	White
Applicable Model	DF25R-250T/Z

To help your SUZUKI OUTBOARD MOTOR run at its best, monitor the charging system functioning with a VOLTMETER.

TRIM GAUGE



34800-93J00-000 042

Gauge Size	2"
Background	Black
Applicable Model	DF40T/ 50T-250T/Z

Magnetic-type gauge shows trim angle for optimum performance and efficiency.



34800-93J11-000 043

Gauge Size	2"
Background	White
Applicable Model	DF40T/50T-250T/Z

Magnetic-type gauge shows trim angle for optimum performance and efficiency.

WATER-PRESSURE GAUGE



34650-93J20-000 044

Gauge Size	2"
Background	Black
Applicable Model	DF40T-250T/Z

Bourdon-tube type gauge measures cooling-water pressure. Select an appropriate INSTALLATION KIT for each model.



34650-93J31-000 045

Gauge Size	2"
Background	White
Applicable Model	DF40T-250T/Z

Bourdon-tube type gauge measures cooling-water pressure. Select an appropriate INSTALLATION KIT for each model.



INSTALLATION KIT for WATER-PRESSURE GAUGE



046

34660-87J00-000

Applicable Model DF40QH-50T

34660-90J02-000

Applicable Model DF60AT-140T/Z

34660-96J00-000

Applicable Model DF150T/Z/175T/Z

34660-93J00-000 046

Applicable Model DF200T/Z-250T/Z

KIT includes fittings and hoses needed for motor to gauge connection.

SUZUKI PRECISION CONTROL
**ELECTRONIC
THROTTLE
AND SHIFT
SYSTEM**



047



048



049

REMOTE-CONTROL KIT for **DUAL ENGINE**

SINGLE STATION		STATION	DUAL STATION			
67000-98J24-000 - DF300T/Z	QTY		First Station 67000-98J24-000	+	Second Station 67000-98J34-000	QTY
			DF300T/Z		DF300T/Z	
67200-98J12-000 049	1	BINNACLE-MOUNT CONTROL KIT or FLUSH-MOUNT CONTROL KIT Applicable Model Contents:	67200-98J12-000 049		67200-98J12-000 049	2
-	-	BINNACLE MOUNT R/C BOX or FLUSH MOUNT R/C BOX	-		-	-
37100-98J02-000 050	1	MAIN SWITCH PANEL	37100-98J02-000 050	1	-	1
37100-98J21-000 052	1	CONTROL PANEL	37100-98J21-000 052	1	37100-98J21-000 052	2
38500-93J90-000 081	1	WARNING BUZZER	38500-93J90-000 081	1	38500-93J90-000 081	2
09407-08401-000	1	WARNING-BUZZER CLAMP	09407-08401-000	1	09407-08401-000	2
-	-	EMERGENCY SWITCH PANEL	-	-	37803-93J02-000	1
36625-98J00-000 063	1	BATTERY LEAD	36625-98J00-000 063	1	-	-
36770-98J01-000 054	1	BOAT CONTROL MODULE (BCM)	36770-98J01-000 054	1	36770-98J01-000 054	2
36775-98J00-000 055	1	BCM HOLDER (L)	36775-98J00-000 055	1	36775-98J00-000 055	2
36776-98J00-000 056	1	BCM HOLDER (R)	36776-98J00-000 056	1	36776-98J00-000 056	2
-	-	BCM-CONNECT CAP	-	-	-	-
33925-93J00-000 058	1	BCM CUSHION	33925-93J00-000 058	1	33925-93J00-000 058	2
36623-98J11-000	1	BCM #1 WIRING HARNESS	36623-98J11-000	1	-	-
-	-	BCM #2 WIRING HARNESS	-	-	36624-98J10-000	1
33926-98J00-000 064	2	TERMINAL RESISTOR	33926-98J00-000 064	2	-	-
36621-98J00-000 061	1	ENGINE WIRING HARNESS	36621-98J00-000 061	1	-	-
-	-	DUAL-STATION WIRING HARNESS	-	-	36622-98J00-000 062	1
09403-13402-000	15	HARNESS CLAMP	09403-13402-000	15	09403-13402-000	25

REMOTE-CONTROL KIT for **SINGLE ENGINE**

SINGLE STATION		STATION	DUAL STATION			
67000-98J03-000 67000-98J61-000 DF300T	QTY		First Station 67000-98J03-000	+	Second Station 67000-98J14-000	QTY
			67000-98J61-000 DF300T		DF300T	
67200-98J02-000 047	1	BINNACLE-MOUNT CONTROL KIT or FLUSH-MOUNT CONTROL KIT Applicable Model Contents:	67200-98J02-000 047		67200-98J02-000 047	2
67200-98J21-000 048	1	BINNACLE MOUNT R/C BOX or FLUSH MOUNT R/C BOX	67200-98J21-000 048	1	-	-
37100-98J01-000 050	1	MAIN SWITCH PANEL	37100-98J01-000 050	1	-	1
37100-98J11-000 051	1	CONTROL PANEL	37100-98J11-000 051	1	37100-98J11-000 051	2
38500-93J90-000 081	1	WARNING BUZZER	38500-93J90-000 081	1	38500-93J90-000 081	2
09407-08401-000	1	WARNING-BUZZER CLAMP	09407-08401-000	1	09407-08401-000	2
-	-	EMERGENCY SWITCH PANEL	-	-	37803-93J02-000	1
36625-98J00-000 063	1	BATTERY LEAD	36625-98J00-000 063	1	-	-
36770-98J01-000 054	1	BOAT CONTROL MODULE (BCM)	36770-98J01-000 054	1	36770-98J01-000 054	2
36775-98J00-000 055	1	BCM HOLDER (L)	36775-98J00-000 055	1	36775-98J00-000 055	2
36776-98J00-000 056	1	BCM HOLDER (R)	36776-98J00-000 056	1	36776-98J00-000 056	2
33911-88BLO-000 057	1	BCM-CONNECT CAP	33911-88BLO-000 057	1	33911-88BLO-000 057	2
33925-93J00-000 058	1	BCM CUSHION	33925-93J00-000 058	1	33925-93J00-000 058	2
36623-98J01-000 065	1	BCM #1 WIRING HARNESS	36623-98J01-000 065	1	-	-
-	-	BCM #2 WIRING HARNESS	-	-	36624-98J10-000 066	1
33926-98J00-000 064	2	TERMINAL RESISTOR	33926-98J00-000 064	2	-	-
-	-	ENGINE WIRING HARNESS	-	-	-	-
-	-	DUAL-STATION WIRING HARNESS	-	-	36622-98J00-000 062	1
09403-13402-000	10	HARNESS CLAMP	09403-13402-000	10	09403-13402-000	20

REMOTE-CONTROL KIT for **TRIPLE ENGINE**

SINGLE STATION		STATION	DUAL STATION			
67000-98J42-000 - DF300T/Z	QTY		First Station 67000-98J42-000	+	Second Station 67000-98J52-000	QTY
			DF300T/Z		DF300T/Z	
67200-98J11-000 049	1	BINNACLE-MOUNT CONTROL KIT or FLUSH-MOUNT CONTROL KIT Applicable Model Contents:	67200-98J11-000 049		67200-98J11-000 049	2
-	-	BINNACLE MOUNT R/C BOX or FLUSH MOUNT R/C BOX	-		-	-
37100-98J00-000 050	1	MAIN SWITCH PANEL	37100-98J00-000 050	1	-	1
37100-98J31-000 053	1	CONTROL PANEL	37100-98J31-000 053	1	37100-98J31-000 053	2
38500-93J90-000 081	1	WARNING BUZZER	38500-93J90-000 081	1	38500-93J90-000 081	2
09407-08401-000	1	WARNING-BUZZER CLAMP	09407-08401-000	1	09407-08401-000	2
-	-	EMERGENCY SWITCH PANEL	-	-	37803-93J00-000 079	1
36625-98J00-000 063	1	BATTERY LEAD	36625-98J00-000 063	1	-	-
36770-98J01-000 054	1	BOAT CONTROL MODULE (BCM)	36770-98J01-000 054	1	36770-98J01-000 054	2
36775-98J00-000 055	1	BCM HOLDER (L)	36775-98J00-000 055	1	36775-98J00-000 055	2
36776-98J00-000 056	1	BCM HOLDER (R)	36776-98J00-000 056	1	36776-98J00-000 056	2
-	-	BCM-CONNECT CAP	-	-	-	-
33925-93J00-000 058	1	BCM CUSHION	33925-93J00-000 058	1	33925-93J00-000 058	2
36623-98J10-000	1	BCM #1 WIRING HARNESS	36623-98J10-000	1	-	-
-	-	BCM #2 WIRING HARNESS	-	-	36624-98J10-000	1
33926-98J00-000 064	2	TERMINAL RESISTOR	33926-98J00-000 064	2	-	-
36621-98J10-000	1	ENGINE WIRING HARNESS	36621-98J10-000	1	-	-
-	-	DUAL-STATION WIRING HARNESS	-	-	36622-98J00-000 062	1
09403-13402-000	18	HARNESS CLAMP	09403-13402-000	18	09403-13402-000	28

SUZUKI PRECISION CONTROL
**ELECTRONIC
 THROTTLE
 AND SHIFT
 SYSTEM**

MAIN SWITCH PANEL



37100-98J02-000 050
 Single ignition with Emergency-stop switch
 Applicable Model DF300T/Z

CONTROL PANEL



37100-98J11-000 051
 for Single-Engine
 Applicable Model DF300T



37100-98J21-000 052
 for Dual-Engine
 Applicable Model DF300T/Z



37100-98J31-000 053
 for Triple-Engine
 Applicable Model DF300T/Z

BOAT CONTROL MODULE (BCM)



36770-98J01-000 054
 Applicable Model DF300T/Z

BCM HOLDER (L/R)



(L) 055

(R) 056

36775-98J00-000 055
 Applicable Model DF300T/Z

36776-98J00-000 056
 Applicable Model DF300T/Z

BCM-CONNECT CAP



33911-88BLO-000 057
 Applicable Model DF300T/Z

BCM CUSHION



33925-93J00-000 058
 Applicable Model DF150T/Z-300T/Z

CONNECTION between ENGINE and CONTROL SYSTEM

MAIN WIRING HARNESS



36620-98J00-000 059
 6.5 meters for control system
 Applicable Model DF300T/Z

36620-98J10-000
 9.5 meters for control system
 Applicable Model DF300T/Z

MAIN-WIRING-HARNESS EXTENSION



36620-98J20-000 060
 2.0 meters for control system
 Applicable Model DF300T/Z

ENGINE WIRING HARNESS



36621-98J00-000 061
 for Dual engines
 Applicable Model DF300T/Z

36621-98J10-000
 for Triple engines
 Applicable Model DF300T/Z

DUAL-STATION WIRING HARNESS



36622-98J00-000 062
 for Dual-station control system
 Applicable Model DF300T/Z

BATTERY LEAD



36625-98J00-000 063
 6.5 meters
 Applicable Model DF300T/Z

TERMINAL RESISTOR



33926-98J00-000 064
 Applicable Model DF300T/Z



BCM #1 WIRING HARNESS



36623-98J01-000 065
 for Single engine and Single (First) station
 Applicable Model DF300T/Z

36623-98J11-000
 for Multiple engines and Single (First) station
 Applicable Model DF300T/Z

BCM #2 WIRING HARNESS



36624-98J01-000 066
 for Single engine and Second station
 Applicable Model DF300T/Z

36624-98J10-000
 for Multiple engines and Second station
 Applicable Model DF300T/Z

MECHANICAL REMOTE CONTROL SYSTEM

REMOTE-CONTROL KIT for SINGLE ENGINE + SINGLE STATION

67000-93J01-000	QTY	67000-93J44-000	QTY	-	QTY
-	-	-	-	67000-93J21-000	-
-	-	-	-	-	-
DF40T/50T/60AT-100T/115T/ 150T/175T/200T/225T/250T	-	DF40T/50T/60AT-100T/115T/ 140T/150T/175T/200T/225T/250T	-	DF40T/50T/60AT-100T/115T/ 140T/150T/175T/200T/225T/250T	-
67200-93J12-000 ⁰⁶⁷	1	67200-93J12-000 ⁰⁶⁷	1	-	-
-	-	-	-	67200-93J30-000 ⁰⁶⁹	1
-	-	-	-	-	-
-	-	34200-93J11-000 ⁰²⁶	1	-	-
-	-	34800-93J11-000 ⁰⁴³	1	-	-
-	-	36620-93J01-000 ⁰⁷⁴	1	-	-
-	-	-	-	-	-
37100-96J21-000	1	37100-96J22-000 ⁰⁷⁶	1	37100-96J21-000	1

REMOTE-CONTROL KIT for DUAL ENGINE + SINGLE STATION

-	QTY	-	QTY	BINNACLE-MOUNT CONTROL KIT	67000-93J11-000	QTY	67000-93J54-000	QTY
67000-93J64-000	-	-	-	FLUSH-MOUNT CONTROL KIT	-	-	-	-
-	-	67000-93J73-000	-	SIDE-MOUNT CONTROL KIT	-	-	-	-
DF40T/50T/60AT-100T/115T/ 140T/150T/175T/200T/225T/250T	-	DF40T/50T/60AT-100T/115T/ 140T/150T/175T/200T/225T/250T	-	Applicable Model	DF40T/50T/60AT-90AT/ 115T/Z-250T/Z	-	DF40T/50T/70AT-250T/Z	-
-	-	-	-	Contents:	-	-	-	-
67200-93J30-000 ⁰⁶⁹	1	-	-	BINNACLE MOUNT R/C BOX	67200-93J22-000 ⁰⁶⁸	1	67200-93J22-000 ⁰⁶⁸	1
-	-	-	-	FLUSH MOUNT R/C BOX	-	-	-	-
-	-	67200-93J01-000	1	SIDE MOUNT R/C BOX	-	-	-	-
34200-93J11-000 ⁰²⁶	1	34200-93J11-000 ⁰²⁶	1	TACHOMETER (Background: White)	-	-	34200-93J11-000 ⁰²⁶	1
34800-93J11-000 ⁰⁴³	1	34800-93J11-000 ⁰⁴³	1	TRIM GAUGE (Background: White)	-	-	34800-93J11-000 ⁰⁴³	1
36620-93J01-000 ⁰⁷⁴	1	36620-93J01-000 ⁰⁷⁴	1	MAIN WIRING HARNESS	-	-	36620-93J01-000 ⁰⁷⁴	1
-	-	-	-	MAIN-WIRING-HARNESS EXTENSION	-	-	36620-93J10-000	1
37100-96J22-000 ⁰⁷⁶	1	-	-	IGNITION SWITCH PANEL	37100-96J10-000	1	37100-96J12-000 ⁰⁷⁷	1

BINNACLE-MOUNT REMOTE CONTROL BOX



67200-93J12-000 ⁰⁶⁷

Single-engine

Applicable Model DF8A-9.9T/15-40T/50T/
60AT-115T/140T/
150T-175T/Z/200T/225T/
250T

Not Applicable Model DF150Z

BINNACLE-MOUNT REMOTE CONTROL BOX



67200-93J22-000 ⁰⁶⁸

Dual-engine

Applicable Model DF40T/50TH/50T/
70AT-250T/Z

Not Applicable Model QH

FLUSH-MOUNT REMOTE CONTROL BOX



67200-93J30-000 ⁰⁶⁹

Single-engine

Applicable Model DF25R/40T/50T/
60AT-100T/115T/140T/Z/
150T/200T/225T/250T

Not Applicable Model DF140WZ/115WT

SIDE-MOUNT REMOTE CONTROL BOX



67200-91J01-000

Single-engine

Applicable Model DF4-6

67200-94J11-000 ⁰⁷⁰

Single-engine

Applicable Model DF8AR/9.9AR/15/15R/25R

Not Applicable Model DF9.9A

67200-93J01-000

Single-engine

Applicable Model DF9.9T/40T/50T/60AT-100T/115T/
140T/150T/175T/200T/225T/250T

CONNECTION between ENGINE and CONTROL SYSTEM

MAIN WIRING HARNESS



36620-93J51-000

5.0 meters for Control system

Applicable Model DF40T-250T/Z

36620-93J01-000 ⁰⁷⁴

6.5 meters for Control system

Applicable Model DF9.9T/40T-250T/Z

36620-93J61-000

8.0 meters for Control system


Applicable Model DF40T-250T/Z

36620-94J01-000

6.5 meters for Control system without
Monitor-signal wire,
Trim-sender wire and PTT-SW wire

Applicable Model DF8AR/9.9AR/15R/25R


SPACER KIT for REMOTE CONTROL BOX



67500-93J00-000 ⁰⁷¹

for Single Binnacle-mount type

Applicable Model DF8A-15R/25R/40T/50T/
60AT-100T/115T/140T/150T/
175T/200T/225T/250T



67500-93J10-000 ⁰⁷²

for Dual Binnacle-mount type

Applicable Model DF40T/50T/70AT-250T/Z



BATTERY LEAD



36625-93J10-000 ⁰⁷³

6.7 meters

Applicable Model DF70AT-250T/Z

MAIN-WIRING-HARNESS EXTENSION

36620-93J10-000

2.0 meters for Control system

Applicable Model DF25R/40T/50T/
60AT-250T/Z

36620-93J40-000

3.0 meters for Control system

Applicable Model DF40T/50T/60AT-90AT/
115T/Z-250T/Z

MECHANICAL REMOTE CONTROL SYSTEM

SWITCH PANEL



IGNITION SWITCH PANEL



37100-96J00-000 075

Single ignition

Applicable Model DF25R/40T-250T/Z

IGNITION SWITCH PANEL



37100-96J22-000 076

Single ignition with
Emergency-stop switch

Applicable Model DF25R/40T/50T/
60AT-250T/Z

IGNITION SWITCH PANEL



37100-96J12-000 077

Dual ignition with
Emergency-stop switch

Applicable Model DF40T-250T/Z

WARNING BUZZER



38500-93J90-000 081

Applicable Model DF25R/40T/50T/
60AT-300T/Z

THRU-HULL-HOSE ATTACHMENT



67300-93J00-000 082

Applicable Model DF150T/Z-300T/Z

TWIN REMOCON ATTACHMENT KIT



67140-95600-000 083

Applicable Model DF9.9T/15/15R/40T/50TH/
50T/70AT-250T/Z

Not Applicable Model DF9.9TH/QH

REMOTE-CONTROL CABLE



67320-93J00-000 084

8 feet 2.44 meters

Applicable Model DF4-6/9.9T/9.9TH/15R/25R/
40T/50T/60AT/
150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J10-000

10 feet 3.05 meters

Applicable Model DF4-6/9.9T/9.9TH/15R/25R/
40T/50T/60AT/
150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J20-000

12 feet 3.66 meters

Applicable Model DF4-6/9.9T/9.9TH/15R/25R/
40T/50T/60AT/
150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J30-000

14 feet 4.27 meters

Applicable Model DF4-6/9.9T/9.9TH/15R/25R/
50T/60AT/150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J40-000

16 feet 4.88 meters

Applicable Model DF4-6/9.9T/9.9TH/15R/25R/
40T/50T/60AT/
150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J50-000

18 feet 5.49 meters

Applicable Model DF9.9T/9.9TH/15R/25R/40T/
50T/60AT/150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J60-000

20 feet 6.10 meters

Applicable Model DF9.9T/9.9TH/15R/25R/40T/
50T/60AT/150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J70-000

22 feet 6.71 meters

Applicable Model DF9.9T/9.9TH/15R/25R/40T/
50T/60AT/150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

67320-93J80-000

24 feet 7.32 meters

Applicable Model DF9.9T/9.9TH/15R/25R/40T/
50T/60AT/150T/Z-250T/Z

Not Applicable Model DF9.9A/9.9AR

GENUINE REMOTE-CONTROL CABLES employ the latest in cable technology. The inner core is encased in nylon, and travels back and forth in a high-density polyethylene liner.

REMOTE-CONTROL ATTACHING KIT

Converts ME model to REMOTE-CONTROL model.



67130-91J00-000 085

Applicable Model DF4-6

67130-94J11-000

Applicable Model DF9.9T/15/15R

Not Applicable Model DF9.9TH



67130-95J01-000 086

Applicable Model DF25/25R

67130-99J00-000

Applicable Model DF8A-9.9AR

CLAMP BRACKET SET (41100-99J00-0EP) is required for installing 67130-99J00-000.

CLAMP BRACKET SET

41100-99J00-0EP

Applicable Model DF8A/8AR/9.9A/9.9AR

Available from December-2009.

LIGHTING SWITCH PANEL



37210-93J00-000 078

Applicable Model DF25R/40T-250T/Z

EMERGENCY SWITCH PANEL



37803-93J00-000 079

Applicable Model DF25R/40T-300T/Z

PTT SWITCH PANEL



37805-93J00-000 080

Applicable Model DF40T-250T/Z

STEERING

TIE-BAR ADAPTER KIT



67620-99E00-000 089

for installation of DUAL-ENGINE TIE-BAR (67600-90J00-000) on DF40T-60T only

Applicable Model DF40T/50T

STEERING EXTENSION KIT



67630-93J00-000 090

for installation of DUAL-ENGINE TIE-BAR (67600-93J00-000)

Applicable Model DF150T/Z-250T/Z

STEERING-CABLE ATTACHMENT



41141-89E00-000 091

Applicable Model DF9.9T-15

Not Applicable Model DF9.9A/9.9AR

Must be used when installing through-tilt-tube steering to ensure steering angles equally to the right and left.

STEERING-BRACKET SUB-ATTACHMENT



67720-93E00-000 092

Applicable Model DF9.9TH-15R

Not Applicable Model DF9.9T

STEERING CABLE SEAL



41161-94400-000 093

Applicable Model DF8AR/9.9AR/9.9T/15R/25R/40T/50T/60AT-250T/Z

Not Applicable Model DF9.9A/9.9TH

STEERING-BRACKET ATTACHMENT



43755-94J01-000 094

Applicable Model DF9.9T/15/15R

43755-94JA0-000

Applicable Model DF9.9T

43755-95J01-000

Applicable Model DF25/25R

Used to connect DRAG LINK.

DRAG-LINK KIT



67700-87L00-000

Applicable Model DF70AT-90AT

67700-93J00-000

Applicable Model DF200T/Z-250T/Z

67700-95J01-000

Applicable Model DF25

67700-96J00-000

Applicable Model DF150T/Z/175T/Z

67701-87J11-000

Applicable Model DF40T/50T/60AT/200T/Z-250T/Z

67701-87L00-000

Applicable Model DF70AT-90AT

67701-90J00-000

Applicable Model DF100T-140T/Z

67701-93E12-000 095

Applicable Model DF9.9TH-15R

Not Applicable Model DF9.9T

67701-94JA0-000

Applicable Model DF9.9T

Not Applicable Model DF9.9TH

67701-95J00-000

Applicable Model DF25/25R

67701-96J00-000

Applicable Model DF150T/Z/175T/Z

Recommended STEERING SYSTEM supplied by **Teleflex** MARINE www.teleflexmarine.com

Order taking, delivery, technical support and warranty for these products are handled by Teleflex. Please consult to local Teleflex distributor or dealer if you need more detail for product information, price, availability and all business terms.

STEERING KIT

BayStar



BAYSTAR

BAYSTAR OUTBOARD SYSTEM - HK4645H

System comprises:	
BayStar Helm 1.4cu" (22.94cc)	HH4314
BayStar Compact Cylinder	HC4645H*
20ft "cut to length" tubing kit	HT4420H
2 x 1 litre hydraulic oil	HO5430

*Note: 115-140hp four stroke 2001 to current model require HC4658H

SeaStar



SEASTAR

SEASTAR OUTBOARD SYSTEM - HK6400

System comprises:	
SeaStar Helm 1.7cu" (27.80cc)	HH5271
SeaStar Pivot Cylinder	HC5345*
2 x 1 litre hydraulic oil	HO5430

Note: 1 x SeaStar hose kits must be ordered separately
*Note: 115-140hp 1996 only requires HC5348, 40-140hp four stroke 1998 to current model and 90hp four stroke 2003 to current model require HC5358.

SeaStar P/A




SEASTAR POWER ASSIST

SEASTAR OUTBOARD POWER ASSIST SYSTEM

System comprises:	
SeaStar Helm 1.7cu" (27.80cc)	HH5271
SeaStar Pivot Cylinder	HC5345*
2 x 1 litre hydraulic oil	HO5430
SeaStar 12v Power Assist Unit	PA1200

Note: 2 x SeaStar hose kits must be ordered separately
*Note: 115-140hp 1996 only requires HC5348, 40-140hp four stroke 1998 to current model and 90hp four stroke 2003 to current model require HC5358.

*For further application information please refer to www.teleflexmarine.com



TIE-BAR KIT

Features

General purpose system.
Single and multiple engine capability.
Total power up to 700 HP
*counter-rotating.

Independent engine tilt for twin engine
Easy steering.
5 turns lock to lock steering response.



Applications

Twin Engine Application for 2010 Year Model Suzuki Outboard Motors

MODEL (4-CYCLE)	PRODUCTION PER.	CYLINDER	TIE BAR KITS		NOTES
			TWIN ENGINE SINGLE CYL.	TWIN ENGINE DUAL CYL.	
DF40/50	1999 - CURRENT MODEL	HC5358	HO6003	HO6002	Requires kit HO5090
DF70A/80A/90A	2009 -	HC5358	HO6003	HO6002	Requires kit HO5090
DF100	2009 -	HC5358	HO6003	HO6002	Requires kit HO5090
DF115/140	2001 - CURRENT MODEL	HC5358	HO6003	HO6002	Requires kit HO5090
DF150/175	2006 - CURRENT MODEL	HC5345	HO6003	HO6002	
DF200/225/250	2004 - CURRENT MODEL	HC5345	HO6003	HO6002	
DF300	2007 - CURRENT MODEL	HC5345	HO6003	HO6002	

Triple Engine Configuration for 2010 Year Model Suzuki Outboard Motors

MODEL (4-CYCLE)	PRODUCTION PER.	CYLINDER	TIE BAR KITS		NOTES
			PORT ENGINE TO DRIVE CYL.	STARBOARD ENGINE TO DRIVE CYL.	
DF150/175	2006 - CURRENT MODEL	HC5345	HO6003	HO6002	See notice
DF200/225/250	2004 - CURRENT MODEL	HC5345	HO6003	HO6002	See notice
DF300	2007 - CURRENT MODEL	HC5345	HO6003	HO6002	See notice

Notice : Two cylinders are required to operate a triple engine set up.

TILLER HANDLE KIT



63001-94J20-0EP

Applicable Model DF15R

63002-87J24-0EP

Applicable Model DF40T/50T

63002-88L00-0EP

Applicable Model DF60A

63002-87L00-0EP

Applicable Model DF70AT-90AT

63002-90J24-0EP 087

with Adjustable Steering Damper

Applicable Model DF100T/115T

CONTENTS: Ignition switch, Engine-stop switches, Wiring harness, Cables and Grommets
TILLER HANDLE KITS are designed for easy installation for selected electric start models.

DUAL-ENGINE TIE-BAR



67600-90J00-000 088

Stainless steel

Applicable Model DF40T/50T/100T-140T/Z

67600-93J00-000

Stainless steel

Applicable Model DF150T/Z-250T/Z

ELECTRICAL PARTS

BATTERY CHARGING KIT

32000-91J00-000

80W

Applicable Model DF4-6

RECTIFIER SET



32801-91J00-000

097

Applicable Model DF4-6

RECEPTACLE KIT



39600-91J00-000

098

Applicable Model DF4-6

ELECTRIC STARTER KIT



31000-94J01-000

Applicable Model DF15

31000-95J00-000

096

Applicable Model DF25

31000-99J00-000

Applicable Model DF8A/9.9A

Converts MZ model into ME model.

BATTERY CHARGING KIT

32000-95J01-000

80W

Applicable Model DF25

RECTIFIER SET



32801-95J01-000

101

Applicable Model DF8A/9.9A/25

RECEPTACLE KIT



39600-95J00-000

102

Applicable Model DF25

BATTERY CHARGING KIT

32000-94J01-000

80W

Applicable Model DF15

RECTIFIER SET



32801-94J01-000

099

Applicable Model DF15

RECEPTACLE KIT



39600-94J01-000

100

Applicable Model DF8A/9.9A/15

BATTERY CHARGING KIT

32000-99J00-000

80W

Applicable Model DF8A/9.9A

RECTIFIER SET



32801-95J01-000

101

Applicable Model DF8A/9.9A/25

RECEPTACLE KIT



39600-94J01-000

100

Applicable Model DF8A/9.9A/15



ANODE



BATTERY ISOLATOR LEAD SET



33830-96J00-000

103

Applicable Model DF150T/Z/175T/Z

33830-98J01-000

Applicable Model DF300T/Z

STATOR & PULSER COIL COMPONENT



32120-94J10-000

12V, 120W

Applicable Model DF15

32120-95J00-000

12V, 180W

Applicable Model DF25

Raises the standard output (12V, 80W) to a larger output (12V, 120 or 180W).

ZINC ANODE for saltwater



41811-98500-000

105

Applicable Model DF9.9T-15R

Not Applicable Model DF9.9A/9.9AR



55300-95500-000

106

Applicable Model DF8A-15R/40T-60ATH



55320-95311-000

107

Applicable Model DF40T-50T



55321-93900-000

108

Applicable Model DF9.9T/9.9TH/15/15R

Not Applicable Model DF9.9A/9.9AR



55321-95J00-000

109

Applicable Model DF2.5/25/25R



55321-90J01-000

110

Applicable Model DF100T-140T/Z



55321-99E00-000

111

Applicable Model DF9.9T/9.9TH/15/15R



55125-96310-000

112

Applicable Model DF25/25R



55125-95500-000

113

Applicable Model DF60T/100T-140T

ALUMINUM ANODE for brackish water, saltwater



55321-87J00-000

114

Applicable Model DF2.5-9.9TH/25-300T/Z

MAGNESIUM ANODE for freshwater



55321-87J10-000

116

Applicable Model DF4-9.9A/9.9AR/15-60ATH/100T-300T/Z

Not Applicable Model DF9.9T/9.9TH



55320-94900-000

115

Applicable Model DF60AT-300T/Z



55321-94910-000

117

Applicable Model DF70AT-300T/Z

FUEL SYSTEM

FUEL-HOSE SOCKET



65750-98505-000 120
Metal, Inner diameter: 11.2 mm
Applicable Model DF4-15R



65750-87J11-000 121
Plastic, Inner diameter: 6.6 mm
Applicable Model DF4-60AT



65750-95500-000 122
Metal, Inner diameter: 13.0 mm
Applicable Model DF8A-140T/Z

FUEL CONNECTOR (ENGINE SIDE)



65720-986B0-000 123
Plastic
Applicable Model DF4-6/9.9T-15R
Not Applicable Model DF9.9A/9.9AR

FUEL CONNECTOR (TANK SIDE)



65740-95D01-000 124
Outer diameter: 13 mm, 1/4" NPT
Applicable Model DF8A-140T/Z

FUEL TANK



65000-99100-000 118
12-litre plastic tank with no fuel-level gauge
Applicable Model DF4-15R

65000-95D01-000 119
25-litre plastic tank with a fuel-level gauge
Applicable Model DF8A-140T/Z

REPLACEMENT FUEL CAP

65520-99100-000
for 12-litre tank with no fuel-level gauge
Applicable Model DF4-15R

65520-95D00-000
for 25-litre tank with a fuel-level gauge
Applicable Model DF8A-140T/Z



PRIMER BULB (SQUEEZE PUMP)

65770-93904-000 125
Small-in & Large-out
Applicable Model DF4-15R

65770-95505-000
Large-in & Large-out
Applicable Model DF8A-9.9AR/25-140T/Z
Not Applicable Model DF9.9T/9.9TH

65770-87D00-000
Large-in & Large-out
Applicable Model DF150T/Z-300T/Z

WATER SEPARATOR / FUEL FILTER



99000-79N12-012 126
Normal size
Applicable Model DF60T-300T/Z

REPLACEMENT FILTER

99000-79N12-011
for Normal size
Applicable Model DF60T-300T/Z

BOWL & DRAIN VALVE ASSEMBLY

99000-79N12-013
for Normal size
Applicable Model DF60T-300T/Z

WATER SEPARATOR / FUEL FILTER



99000-79N12-015 127
Compact size
Applicable Model DF40T-140T/Z

REPLACEMENT FILTER

99000-79N12-014
for Compact size
Applicable Model DF40T-140T/Z

BOWL & DRAIN VALVE ASSEMBLY

99000-79N12-016
for Compact size
Applicable Model DF40T-140T/Z

FUEL-HOSE COMPONENT



65700-91J13-000
for 25-litre plastic tank to engine
Applicable Model DF4-9.9AR/15/15R
Not Applicable Model DF9.9T/9.9TH

65700-90J12-000
for 12-litre plastic tank to engine
Applicable Model DF70AT-140T/Z


65700-93J00-000 128
for 25-litre plastic tank to engine
Applicable Model DF150T/Z-300T/Z

65700-87D80-000
for 12-litre plastic tank to engine
Applicable Model DF15/15R

65700-87J12-000
for 25-litre plastic tank to engine
Applicable Model DF8A-9.9AR/25-60AT
Not Applicable Model DF9.9T/9.9TH

65700-94JB1-000
for 25-litre plastic tank to engine
Applicable Model DF9.9T/15
Not Applicable Model DF9.9TH

Application Chart for FUEL HOSE COMPONENT



FUEL HOSE COMPONENT		SOCKET			HOSE			SQUEEZE PUMP	HOSE			SOCKET		
Part Number	A Length (mm)	B I/D (mm)	Part Number	C Length (mm)	I/D (mm)	O/D (mm)	D Length (mm)		I/D (mm)	O/D (mm)	Material	E I/D (mm)	Part Number	
65700-91J13-000	1960	6.3	65750-87J11-000	700	Large	7.3 12.5	65770-93903-000	1100	Small	5.3 10.5	Metal	11	65750-98505-000	
65700-90J12-000	1240	-	-	(no hose)	-	-	65770-95504-000	1100	Large	7.3 12.5	Metal	13	65750-95500-000	
65700-93J00-000	2370	-	-	(no hose)	-	-	65770-87D00-000	2250	Large	9.0 14.0	(no socket)	-	-	
65700-87D80-000	2560	11	65750-98505-000	300	5.3 10.5	65770-95541-000	2090		7.3 12.5	Metal	13	65750-95500-000		
65700-87J12-000	1970	6.3	65750-87J11-000	700	7.3 12.5	65770-95505-000	1100		7.3 12.5	Metal	13	65750-95500-000		
65700-94JB1-000	2560	11	65750-98505-000	300	5.3 10.5	65770-95541-000	2090		7.3 12.5	Metal	13	65750-95500-000		

PROPELLER



HARDWARE FOR PROPELLER

Applicable Model	STOPPER		PROPELLER BUSH		HARDWARE KIT	Contents of HARDWARE KIT			
		SPACER				SPACER	WASHER	NUT	COTTER PIN
DF2.5	-	-	-	-	N/A	-	-	-	(09204-02001-000)
DF4/5/6	57635-91J00-000	-	58120-91J00-000	Press-In	N/A	-	-	(58130-91J01-000)	(09204-03003-000)
DF8A/9.9A	57632-94J00-000	-	58120-93701-000	Press-In	57630-99J00-000	57633-93901-000	09160-12066-000	59152-94J00-000	09204-02004-000
DF9.9/15	57632-93902-000	-	58120-93701-000	Press-In	57630-93900-000	57633-93901-000	09160-12066-000	09141-12005-000	09204-02004-000
DF9.9 with HIGH THRUST propeller	57632-94J00-000	-	58120-94JA0-000	Press-In	57630-93900-000	57633-93901-000	09160-12066-000	09141-12005-000	09204-02004-000
DF25	57632-95J00-000	-	58120-96401-000	Press-In	57630-96300-000	57633-96300-000	09160-14028-000	09141-14008-000	09204-03003-000
DF40/50	57632-95305-000	-	58120-95300-000	Press-In	57630-94300-000	57633-94300-000	09160-18028-000	09141-18005-000	09204-03003-000
DF60A	57632-95305-000	-	58120-88L00-000	Press-In	57630-94300-000	57633-94300-000	09160-18028-000	09141-18005-000	09204-03003-000
DF70A/80A/90A	57632-87L00-000	-	58120-90J00-000	Press-In	57630-90J00-000	57633-90J02-000	09160-18028-000	09141-18005-000	09204-03003-000
DF100/115 T model (Right-Hand-Rotation)	57635-90J01-000	57632-90J00-000	58120-90J00-000	Press-In	57630-90J00-000	57633-90J02-000	09160-18028-000	09141-18005-000	09204-03003-000
DF115 Z model (Counter-Rotation)	57635-92J01-000	-	58120-90J00-000	Press-In	57630-90J00-000	57633-90J02-000	09160-18028-000	09141-18005-000	09204-03003-000
DF140	57635-92J01-000	-	58120-90J00-000	Press-In	57630-90J00-000	57633-90J02-000	09160-18028-000	09141-18005-000	09204-03003-000
DF150-300	57632-93J10-000	-	58105-93J10-000	Press-In	57630-92E00-000	57633-87D30-000	09160-18028-000	09141-18005-000	09204-03003-000

*Rotation: RR: Right-Hand-Rotation model, CR: Counter-Rotation model

model	type	material	blade	diameter	pitch	rotation*	description	part number
DF2.5	A510	Aluminum	3	7 3/8	5 3/8	RR		58111-97J00-019
DF4	C601	Aluminum	3	7 1/2	6	RR		58110-91J00-019
DF5	C611	Aluminum	3	7 1/2	6 1/2	RR		58110-91J10-019
DF6	C701	Aluminum	3	7 1/2	7	RR		58110-91J20-019
DF9.9	M701	Aluminum	3	9 1/4	7	RR		58100-93703-019
	M821	Aluminum	3	9 1/4	8	RR	THICK	58100-91D00-019
	M901	Aluminum	3	9 1/4	9	RR		58100-94J00-019
	M911	Aluminum	3	9 1/4	9	RR	THICK	58100-93763-019
	M1001	Aluminum	3	9 1/4	10	RR		58100-93733-019
	M1011	Aluminum	3	9 1/4	10	RR	THICK	58100-93773-019
	M1101	Aluminum	3	9 1/4	11	RR		58100-93743-019
	-	Aluminum	4	10	5	RR	High Thrust	58100-94JA0-019
DF8A	M701	Aluminum	3	9 1/4	7	RR		58100-93703-019
DF9.9A	M821	Aluminum	3	9 1/4	8	RR	THICK	58100-91D00-019
DF15	M901	Aluminum	3	9 1/4	9	RR		58100-94J00-019
	M911	Aluminum	3	9 1/4	9	RR	THICK	58100-93763-019
	M1001	Aluminum	3	9 1/4	10	RR		58100-93733-019
	M1011	Aluminum	3	9 1/4	10	RR	THICK	58100-93773-019
	M1101	Aluminum	3	9 1/4	11	RR		58100-93743-019
DF25	P911	Aluminum	3	10 1/4	9	RR	THICK	58100-96370-019
	P1001	Aluminum	3	10 1/4	10	RR		58100-96410-019
	P1101	Aluminum	3	10 1/4	10	RR	THICK	58100-96470-019
	P101	Aluminum	3	10 1/4	11	RR		58100-96420-019
	P1201	Aluminum	3	10 1/4	12	RR		58100-96430-019
	P1211	Aluminum	3	10 1/4	12	RR	THICK	58100-96480-019
	P1301	Aluminum	3	10 1/4	13	RR		58100-96440-019
	P1311	Aluminum	3	10 1/4	13	RR	THICK	58100-96490-019
	P1401	Aluminum	3	10 1/4	14	RR		58100-95D00-019
	P1501	Aluminum	3	10 1/4	15	RR		58100-96460-019
DF40	S900	Aluminum	3	11 1/2	9	RR		58100-94302-019
DF50	S1000	Aluminum	3	11 1/2	10	RR		58100-95212-019
	S1100	Aluminum	3	11 1/2	11	RR		58100-95222-019
	S1200	Aluminum	3	11 5/8	12	RR		58100-95393-019
	S1301	Aluminum	3	11 1/2	13	RR		58100-94313-019
	S1400	Aluminum	3	11 3/8	14	RR		58100-95353-019
	S1500	Aluminum	3	11 1/4	15	RR		58100-95363-019
	S1600	Aluminum	3	11 1/8	16	RR		58100-95373-019
	S1700	Aluminum	3	11	17	RR		58100-95382-019
	SS1300	Stainless	3	11 1/2	13	RR		58100-94401-000
	SS1400	Stainless	3	11 3/8	14	RR		58100-94411-000
	SS1600	Stainless	3	11 1/8	16	RR		58100-94431-000
DF60A	S900	Aluminum	3	11 1/2	9	RR		58100-88L00-019
	S1000	Aluminum	3	11 1/2	10	RR		58100-88L10-019
	S1100	Aluminum	3	11 1/2	11	RR		58100-88L20-019
	S1200	Aluminum	3	11 5/8	12	RR		58100-88L30-019
	S1301	Aluminum	3	11 1/2	13	RR		58100-88L40-019
	S1400	Aluminum	3	11 3/8	14	RR		58100-88L50-019
	S1500	Aluminum	3	11 1/4	15	RR		58100-88L60-019
	S1600	Aluminum	3	11 1/8	16	RR		58100-88L70-019
	S1700	Aluminum	3	11	17	RR		58100-88L80-019
(tentative)	SS1300	Stainless	3	11 1/2	13	RR		58200-88L00-000
(tentative)	SS1400	Stainless	3	11 3/8	14	RR		58200-88L10-000
(tentative)	SS1600	Stainless	3	11 1/8	16	RR		58200-88L30-000



model	material	blade	diameter	pitch	rotation*	part number
DF70A	Aluminum	3	14	13	RR	58100-87L00-019
DF80A	Aluminum	3	13 7/8	15	RR	58100-87L10-019
DF90A	Aluminum	3	13 3/4	17	RR	58100-87L20-019
	Aluminum	3	13 3/4	19	RR	58100-87L30-019
	Aluminum	3	13 3/4	21	RR	58100-87L40-019
	Aluminum	3	13 3/4	23	RR	58100-87L50-019
	Aluminum	3	13 1/2	15	RR	58100-90J41-019
	Aluminum	3	14	17	RR	58100-90J01-019
	Aluminum	3	14	19	RR	58100-90J11-019
	Aluminum	3	14	21	RR	58100-90J21-019
	Aluminum	3	14	23	RR	58100-90J31-019
	Stainless	3	14 1/4	18	RR	58200-90J00-000
	Stainless	3	14 1/4	20	RR	58200-90J10-000
	Stainless	3	14 1/4	22	RR	58200-90J20-000
	Stainless	3	14 1/4	24	RR	58200-90J30-000
DF100	Aluminum	3	13 1/2	15	RR	58100-90J41-019
DF115	Aluminum	3	14	17	RR	58100-90J01-019
DF140	Aluminum	3	14	19	RR	58100-90J11-019
	Aluminum	3	14	21	RR	58100-90J21-019
	Aluminum	3	14	23	RR	58100-90J31-019
	Stainless	3	14 1/4	18	RR	58200-90J00-000
	Stainless	3	14 1/4	20	RR	58200-90J10-000
	Stainless	3	14 1/4	22	RR	58200-90J20-000
	Stainless	3	14 1/4	24	RR	58200-90J30-000
	Stainless	3	14 1/4	18	CR	58200-92J00-000
	Stainless	3	14 1/4	20	CR	58200-92J10-000
	Stainless	3	14 1/4	22	CR	58200-92J20-000
	Stainless	3	14 1/4	24	CR	58200-92J30-000

model	material	blade	diameter	pitch	rotation*	part number
DF150	Stainless	3	16	17	RR	58200-93J00-000
DF175	Stainless	3	16	18 1/2	RR	58200-93J10-000
DF200	Stainless	3	16	20	RR	58200-93J20-000
DF225	Stainless	3	16	21 1/2	RR	58200-93J30-000
DF250	Stainless	3	16	23	RR	58200-93J40-000
DF300	Stainless	3	16	24 1/2	RR	58200-93J50-000
	Stainless	3	16	26	RR	58200-93J60-000
	Stainless	3	16	27 1/2	RR	58200-93J70-000
	Stainless	3	16	17	CR	58200-93JE0-000
	Stainless	3	16	18 1/2	CR	58200-93JA0-000
	Stainless	3	16	20	CR	58200-93JB0-000
	Stainless	3	16	21 1/2	CR	58200-93JC0-000
	Stainless	3	16	23	CR	58200-93JD0-000
	Stainless	3	16	24 1/2	CR	58200-93JE0-000
	Stainless	3	16	26	CR	58200-93JG0-000
	Stainless	3	15 1/2	17	RR	58200-96J00-000
	Stainless	3	15 1/4	19	RR	58200-96J10-000
	Stainless	3	15	21	RR	58200-96J20-000
	Stainless	3	14 3/4	23	RR	58200-96J30-000
	Stainless	3	14 1/2	25	RR	58200-96J40-000
	Stainless	3	14 1/2	27	RR	58200-96J50-000
	Stainless	3	15 1/2	17	CR	58200-96JA0-000
	Stainless	3	15 1/4	19	CR	58200-96JB0-000
	Stainless	3	15	21	CR	58200-96JC0-000
	Stainless	3	14 3/4	23	CR	58200-96JD0-000
	Stainless	3	14 1/2	25	CR	58200-96JE0-000
	Stainless	3	14 1/2	27	CR	58200-96JF0-000



CARE ITEM

MAINTENANCE ITEM

ENGINECOVER



68110-96110-000

Applicable Model for DF4-15

68110-94400-000 ¹²⁹

Applicable Model for DF25

68110-94510-000

Applicable Model for DF40-60

FLUSH-HOSE ATTACHMENT



55181-95200-000 ¹³⁰

Applicable Model DF4-15/40T/50T

Not Applicable Model DF9.9A/9.9AR



17917-87L00-000 ¹³¹

Applicable Model DF25/25R/60T-300T/Z

LIQUID GASKET



99000-31120-000 ¹³²

SILICONE SEAL 1212C

50 grams (1.7 oz)



99000-31140-000 ¹³³

1207B (BLACK)

100 grams (3.4 oz)

PAINT



99000-10109-01T ¹³⁴

Francois white

90 grams (3.0 oz)

99000-10109-0EP

Metallic shadow black

90 grams (3.0 oz)

GREASE



99000-25011-000 ¹³⁵

SUPER GREASE-A

450 grams (15.8 oz) for Crank oil seal



99000-25350-000 ¹³⁶

WATER RESISTANT GREASE EP2

250 grams (8.8 oz)



99000-25140-000 ¹³⁷

MOLY PASTE

50 grams (1.7 oz)

THREAD LOCK



99000-32020-000 ¹³⁸

1333B (RED)

50 grams (1.7 oz)



99000-32050-000 ¹³⁹

1342 (BLUE)


50 grams (1.7 oz)



SUZUKI APPROVED GENUINE OIL by MOTUL

These products are supplied directly by MOTUL. Please note that these oils are not available at some countries. Please contact with local distributor of MOTUL.

Suzuki and MOTUL have been in partnership in MotoGP since 1988. Extending this trusted relationship led to the development of new Suzuki Marine Oils. These ranges of oils have excellent oxidation stability and provide outstanding rust protection under severe operating conditions.



GEAR OIL ¹⁴⁰

SAE 90, API GL-5

0.35 litre



4-STROKE ENGINE OIL ¹⁴¹

SAE 10W-30 Semi-synthetic

5 litre FCW

4-STROKE ENGINE OIL ¹⁴²

SAE 10W-40 Semi-Synthetic

5 litre FCW

part name	volume	part number	DF300	DF250	DF225	DF200	DF175	DF150	DF140	DF115	DF100	DF90A	DF80A	DF70A	DF60	DF50	DF40	DF25	DF15	DF9.9	DF6	DF5	DF4	DF2.5
LIQUID GASKET SILICONE SEAL 1212C	50 grams (1.7 oz)	99000-31120-000 ¹³²	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
LIQUID GASKET 1207B (BLACK)	100 grams (3.4 oz)	99000-31140-000 ¹³³	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
GREASE SUPER GREASE-A	450 grams (15.8 oz)	99000-25011-000 ¹³⁵	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-
GREASE WATER RESISTANT GREASE EP2	250 grams (8.8 oz)	99000-25350-000 ¹³⁶	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
GREASE MOLY PASTE	50 grams (1.7 oz)	99000-25140-000 ¹³⁷	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
THREAD LOCK 1333B (RED)	50 grams (1.7 oz)	99000-32020-000 ¹³⁸	0	0	0	0	0	0	0	0	0	0	0	0	0	-	-	0	0	0	-	-	-	-
THREAD LOCK 1342 (BLUE)	50 grams (1.7 oz)	99000-32050-000 ¹³⁹	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

0: Available - : Not available

APPLICATION CHART for 2010 MODEL

Items and their part numbers showing in the application chart are typically recommended, and applicable to 2010 year models of engines. Please consult your local dealers regarding rigging-parts and accessories for the other year models of engines.

page	Part Name / Description	DF300	DF200/225/250	DF150/175	DF140	DF100/115	DF70A/80A/90A	DF60A	DF40/50	DF25	DF15	DF9.9T only	DF8A/9.9A	DF4/5/6
12, 16	REMOTE CONTROL BOX													
	Binnacle-mount for Single-Engine	67200-98J02-000	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	67200-93J12-000 ⁰⁶⁷	-	-
	Binnacle-mount for Dual-Engine	67200-98J12-000	67200-93J22-000 ⁰⁶⁸	67200-93J22-000 ⁰⁶⁸	67200-93J22-000 ⁰⁶⁸	67200-93J22-000 ⁰⁶⁸	67200-93J22-000 ⁰⁶⁸	-	67200-93J22-000 ⁰⁶⁸	-	-	-	-	-
	Flush-mount for Single-Engine	67200-98J21-000	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	67200-93J30-000 ⁰⁶⁹	-	-	-
	Side-mount for Single-Engine	-	67200-93J01-000	67200-93J01-000	67200-93J01-000	67200-93J01-000	67200-93J01-000	67200-93J01-000	67200-93J01-000	67200-94J11-000 ⁰⁷⁰	67200-94J11-000 ⁰⁷⁰	67200-93J01-000	67200-94J11-000 ⁰⁷⁰	67200-91J01-000
12, 16	Binnacle-mount REMOTE CONTROL KIT													
	for Single-Engine + Single-station	67000-98J03-000	67000-93J01-000	67000-93J01-000	67000-93J01-000	67000-93J01-000	67000-93J01-000	67000-93J01-000	67000-93J01-000	-	-	-	-	-
	for Single-Engine + Second-station	67000-98J14-000	-	-	-	-	-	-	-	-	-	-	-	-
	for Dual-Engine + Single-station	67000-98J24-000	67000-93J11-000	67000-93J11-000	67000-93J11-000	67000-93J11-000	67000-93J11-000	67000-93J11-000	67000-93J11-000	-	-	-	-	-
	for Dual-Engine + Second-station	67000-98J34-000	-	-	-	-	-	-	-	-	-	-	-	-
	for Triple-Engine + Single-station	67000-98J42-000	-	-	-	-	-	-	-	-	-	-	-	-
	for Triple-Engine + Second-station	67000-98J52-000	-	-	-	-	-	-	-	-	-	-	-	-
12, 16	Flush-mount REMOTE CONTROL KIT													
	for Single-Engine + Single-station	67000-98J61-000	67000-93J21-000	67000-93J21-000	67000-93J21-000	67000-93J21-000	67000-93J21-000	67000-93J21-000	67000-93J21-000	-	-	-	-	-
			67000-93J64-000	67000-93J64-000	67000-93J64-000	67000-93J64-000	67000-93J64-000	67000-93J64-000	67000-93J64-000					
17	Side-mount REMOTE CONTROL KIT													
	for Single-Engine + Single-station	-	67000-93J73-000	67000-93J73-000	67000-93J73-000	67000-93J73-000	67000-93J73-000	67000-93J73-000	67000-93J73-000	-	-	-	-	-
16	SPACER KIT for REMOTE CONTROL BOX													
	for Single Binnacle-mount type	-	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	67500-93J00-000 ⁰⁷¹	-
	for Dual Binnacle-mount type	-	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	67500-93J10-000 ⁰⁷²	-	-	-	-	-
19	REMOTE-CONTROL CABLE	-	See page 19	See page 19	-	-	-	See page 19	See page 19	See page 19	See page 19	See page 19	See page 19	See page 19
19	REMOTE-CONTROL ATTACHING KIT	-	-	-	-	-	-	-	-	67130-95J01-000 ⁰⁸⁶	67130-94J11-000	67130-94J11-000	67130-99J00-000	67130-91J00-000 ⁰⁸⁵
15, 17	MAIN WIRING HARNESS													
	5.0 meters	-	36620-93J51-000	36620-93J51-000	36620-93J51-000	36620-93J51-000	36620-93J51-000	36620-93J51-000	36620-93J51-000	-	-	-	-	-
	6.5 meters	36620-98J00-000 ⁰⁵⁹	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-93J01-000 ⁰⁷⁴	36620-94J01-000	36620-94J01-000	36620-93J01-000 ⁰⁷⁴	36620-94J01-000	-
	8.0 meters	-	36620-93J61-000	36620-93J61-000	36620-93J61-000	36620-93J61-000	36620-93J61-000	36620-93J61-000	36620-93J61-000	-	-	-	-	-
	9.5 meters	36620-98J10-000	-	-	-	-	-	-	-	-	-	-	-	-
15, 17	MAIN-WIRING-HARNESS EXTENSION													
	2.0 meters	36620-98J20-000 ⁰⁶⁰	36620-93J10-000	36620-93J10-000	36620-93J10-000	36620-93J10-000	36620-93J10-000	36620-93J10-000	36620-93J10-000	36620-93J10-000	-	-	-	-
	3.5 meters	-	36620-93J40-000	36620-93J40-000	36620-93J40-000	36620-93J40-000	36620-93J40-000	36620-93J40-000	36620-93J40-000	-	-	-	-	-
15, 17	BATTERY LEAD	36625-98J00-000 ⁰⁶³	36625-93J10-000 ⁰⁷³	36625-93J10-000 ⁰⁷³	36625-93J10-000 ⁰⁷³	36625-93J10-000 ⁰⁷³	36625-93J10-000 ⁰⁷³	-	-	-	-	-	-	-
18	IGNITION SWITCH PANEL													
	Single ignition	-	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	37100-96J00-000 ⁰⁷⁵	-	-	-
	Single ignition + Emergency-stop switch	-	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	37100-96J22-000 ⁰⁷⁶	-	-	-
	Dual ignition + Emergency-stop switch	-	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	37100-96J12-000 ⁰⁷⁷	-	-	-	-	-
14	MAIN SWITCH PANEL	37100-98J02-000 ⁰⁵⁰	-	-	-	-	-	-	-	-	-	-	-	-
14	CONTROL PANEL													
	for Single engine	37100-98J11-000 ⁰⁵¹	-	-	-	-	-	-	-	-	-	-	-	-
	for Dual engine	37100-98J21-000 ⁰⁵²	-	-	-	-	-	-	-	-	-	-	-	-
	for Triple engine	37100-98J31-000 ⁰⁵³	-	-	-	-	-	-	-	-	-	-	-	-
18	EMERGENCY SWITCH PANEL	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	37803-93J00-000 ⁰⁷⁹	-	-	-
18	PTT SWITCH PANEL	-	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	37805-93J00-000 ⁰⁸⁰	-	-	-
18	LIGHTING SWITCH PANEL	-	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	37210-93J00-000 ⁰⁷⁸	-	-	-
23	STATOR & PULSER COIL COMPONENT	-	-	-	-	-	-	-	-	32120-95J00-000 ¹⁰⁴	32120-94J10-000	-	-	-
22	ELECTRIC STARTER KIT	-	-	-	-	-	-	-	-	31000-95J00-000 ⁰⁹⁶	31000-94J01-000	-	31000-99J00-000	-
22	BATTERY CHARGING KIT	-	-	-	-	-	-	-	-	32000-95J01-000	32000-94J01-000	-	32000-99J00-000	32000-91J00-000
23	BATTERY ISOLATOR LEAD SET	33830-98J01-000	-	33830-96J00-000 ¹⁰³	-	-	-	-	-	-	-	-	-	-
23	ANODE	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23	See page 23
20	TILLER HANDLE KIT	-	-	-	-	63002-90J24-0EP ⁰⁸⁷	63002-87L00-0EP	63002-88L00-0EP	63002-87J24-0EP	-	63001-94J20-0EP	-	-	-
20	STEERING EXTENSION KIT	-	67630-93J00-000 ⁰⁹⁰	67630-93J00-000 ⁰⁹⁰	-	-	-	-	-	-	-	-	-	-
20	DRAG-LINK KIT	-	67700-93J00-000	67700-96J00-000	67701-90J00-000	67701-90J00-000	67701-87L00-000	67701-87J11-000	67701-87J11-000	67700-95J01-000	67701-93E12-000 ⁰⁹⁵	67701-94JA0-000	67701-99J00-000	-
20	STEERING-BRACKET ATTACHMENT	-	-	-	-	-	-	-	-	43755-95J00-000	43755-94J01-000 ⁰⁹⁴	43755-94JA0-000	43755-99J00-000	-
20	DUAL-ENGINE TIE-BAR	-	67600-93J00-000	67600-93J00-000	67600-90J00-000 ⁰⁸⁸	67600-90J00-000 ⁰⁸⁸	-	-	67600-90J00-000 ⁰⁸⁸	-	-	-	-	-
20	TIE-BAR ADAPTER KIT	-	-	-	-	-	-	-	67620-99E00-000 ⁰⁸⁹	-	-	-	-	-
24	FUEL TANK	-	-	-	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-95D01-000 ¹¹⁹	65000-99100-000 ¹¹⁸	65000-99100-000 ¹¹⁸	65000-91100-000 ¹¹⁸
25	FUEL-HOSE COMPONENT	65700-93J00-000 ¹²⁸	65700-93J00-000 ¹²⁸	65700-93J00-000 ¹²⁸	65700-90J12-000	65700-90J12-000	65700-90J12-000	65700-87J13-000	65700-87J13-000	65700-87J13-000	65700-91J13-000	65700-94JC2-000	65700-91J13-000	65700-91J13-000
26	PROPELLER	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	See page 26-27	58100-94JA0-000	See page 26-27	See page 26-27